

1. When the kit arrives everything is there except the instructions printed out. You have to go to the link I placed above. Lay it all out and take a big look.



2. Put the frame together since you will be using this for a reference in a short while. The two sides are the longer sections with tracks and then you have a front and back. The front has a rectangle hole for the latching the top when it is closed. This is different from the rear, which has no hole. The four 90 degree brackets are what will connect it all together. These brackets will be on the inside roof surface, bolting to the frame that will be on the outside during final install.

3.

