

If you have the headliner option on your ragtop you will have to secure the back of the headliner to the frame.

1. You are provided with an aluminum strip with the holes already drilled. This is what will hold your headliner up and secure it to the frame.



2. I placed some 3m double sided tape used for automotive molding on the backside of the strip to help hold the fabric in place behind the strip after it is installed using the self tapping screws.



3. Hold the strip up in front of the rear section of the frame with the fabric behind it and screw the self tapping screws through the holes in the strip, through the fabric and into the frame.



4. Cut the excess fabric and DONE.